MODE D'EMPLOI

INSTRUCTIONS FOR USE

RECHAUD-FOUR

COOKER WITH OVEN

LT 1 LT 2

INSTRUCTIONS D'UTILISATION

INSTALLATION

Pour obtenir la meilleure utilisation possible, il est nécessaire de prévoir une bonne circulation d'air autour de l'appareil. Celui-ci doit être installé à 20 mm au moins des parois adjacentes.

BRANCHEMENT

L'appareil est livré pour utilisation au gaz Butane (28 MB) et au Propane (37 MB).

ALLUMAGE DU RECHAUD

Sélectionner le brûleur approprié. Présenter une allumette allumée. Tourner le bouton correspondant pour obtenir le débit maximum.
Tenir appuyé le bouton dans cette position pendant 10 à 15 secondes pour libérer la sécurité du thermocouple.

ALLUMAGE DU FOUR

Utiliser le bouton situé sur la gauche, signalé par le symbole du four. Présenter une allumette près du trou situé à l'avant du four. Tourner le bouton pour obtenir le débit maximum. Tenir appuyé le bouton dans cette position pendant 10 à 15 secondes pour libérer la sécurité thermocouple. Avant de fermer la porte du four, s'assurer que la rampe brûleur est correctement allumée.
Avant d'utiliser le four, le laisser chauffer à vide pendant 15 minutes.
Poser votre plat de cuisson sur la grille adéquate et jamais sur la plaque inférieure du four.

CONSEILS

Choisir le brûleur le plus approprié à l'ustensile de cuisson utilisé. Ajuster la flamme au moyen du bouton pour éviter qu'elle ne déborde de l'ustensile utilisé.

ENTRETIEN

Les surfaces inox doivent être nettoyées au moyen d'une éponge humide additionnée d'un produit détergent spécifique à l'inox.
Les surfaces émaillées doivent être nettoyées au moyen d'une éponge humide additionnée d'un produit détergent approprié à l'émail.
Ne jamais laisser sur les surfaces des jus de fruit, du vin rouge, des liquides salés.

ATTENTION ! Ne jamais utiliser de produits détergents abrasifs.
Nettoyage des brûleurs : utiliser une éponge humide additionnée de savon ou d'un produit détergent approprié. Si les trous des brûleurs sont bouchés, ne jamais utiliser d'objets métalliques, ils pourraient modifier le diamètre des trous, entraînant un mauvais fonctionnement de l'appareil.

ATTENTION AUX TEMPERATURES DE CONTACT

Ne jamais toucher le hublot et l'encadrement de la porte, la cheminée et les parties arrières. Ne jamais mettre la partie arrière au contact de bois ou de plastique. Assurez-vous que l'installation soit bien ventilée, en particulier les parties basses et arrières.

MODALITY OF USE

INSTALLATION

For a correct use it is necessary to provide a good air circulation around the appliance which must be placed at a minimum distance of 20 mm from the adjacent wall.

CONNECTION

The appliance is delivered ready to be used by butano (28 MBAR.) and by Propane (37 MBAR.).

BURNERS IGNITION

Draw a match near the selected burner. Draw the knob forward the big flame, which corrisponds to the maximum fire intensity, press the knob maintaining it in this position for 10/15 seconds in order to permit the security valve to enter upon its duties.

OVEN IGNITION

Act on the knob on the left, indicated with the symbol of the oven. Draw a match near the front hole of the oven.
Draw the knob near the big flame which corrisponds to the maximum fire intensity, press the knob maintaining it in this position for 10/15 seconds in order to permit the security valve to enter upon its duties. Before closing the oven door, make sure the burner to be properly turned on.
You are exorted to leave the oven hot and empty for 15 minutes before using it.
You must always put the hot plate on the suitable drippin-g-tray and never on the heat diffusor below.

ADVICES

Choose the most suitable burner to the dimensions of the vessel, adjust the flame varying the position of the knob between the «big flame» and the «small flame» in order to forbid the flame to come out from the surface of the vessel.

MAINTENANCE

The steel surfaces must be cleaned with a damp sponge added up to a specific detergent product for steel.
The enameled surfaces must be cleaned with a damp sponge added up to a specific detergent product for enamels.
Never leave juices, vinegar drops, acid or salty liquids on the surfaces for a long time.

MIND

Never use detergent abrasive powders.
Spartifiamma cleaning : if they are very durty use a damp sponge with some soap or with a detergent product. If the holes are pluged, never use metal objects, they could vary the hole diameter with the consequent imperfect working.

MIND THE EXTERNAL TEMPERATURES

Never touch with hands : glass, door frames. Chimney and back parts. Lower outer bottom.
Never draw the back parts near wood, rolled or plastic, make sure the appliance to be always well windy, in particular the bottom and the back parts.

Electrolux
INDUSTRIE

Siège social : 30, Bd. Malesherbes - 75008 PARIS
BUREAUX COMMERCIAUX :
43, Av. Félix Louat - B.P. 136 - 60307 SENLIS CEDEX - Tél. (4) 453.30.66
S.A. au capital de 2 800 000 F - RCS Paris B 542 108 972

PAE 2500 0058 - Imprimerie Electrolux Revin - Juin 1985